

CALL SERV Information Sheet

If unit has **CALL SERV** displayed and the unit appears to be heating properly, proceed as follows:

1. Door **MUST** be CLOSED.
2. Unit must be in OFF condition (display blank) or Initial Power-Up mode (dash lines)




OFF condition



Initial Power-Up

NOTE: Pads will not beep during this procedure.

3. Press **HIDDEN** pad on the Top Touch panel.



4. Press **1, 3, 5, 7,** and **9** pads on the Side Touch Panel.

5. Display should then show **SErv** (Service Test Mode)



6. Press pad **0** to clear **CALL SERV** from the display. Display will indicate **CLr**



7. Press **STOP/RESET** pad to exit the Service Test Mode.
8. Place a 1 quart water load inside the oven cavity.
9. Use a Pre-programmed pad to operate the oven for at least 10 seconds.
10. Does **CALL SERV** appear in the display?
 - NO – oven is ready for normal use
 - YES – call 866-426-2621 to arrange service